

# Kodiak Tent Setup Instructions

Unfold the tent and spread it out in the desired position. Be sure the door zipper is closed. Stake out the corners of the floor- firm but not tight. Put in the rest of the stakes between the corners.

## CENTER POLE:




Assemble the pole and insert the pin through the inside harness and grommet in the center of the roof. Push the pole up raising the tent, and place the butt of the pole in the center of the tent.

## FRONT & BACK POLES:


Assemble the poles and insert the long pin through the inside harness and grommet in the ends. Push the poles up raising the tent, and place the butt of the pole in the center of each end. Attach the guy rope to the pole pins and guy them out with a rope & stake.

## SIDE POLES:

Insert the side poles through the grommets on each side of the tent. Guy out the poles with the rope & stake.



8-SIDE POLES



## OPTIONAL FLY

Be sure to get at least the center fly grommet over the center pole pin before raising the center pole. The end grommets can be placed over the end poles as they are raised. Place the plastic protective caps over the side poles and guy out the sides.

Plastic Cap on Side & Corner Poles

