




# HOW TO SET UP YOUR YELLOWSTONE TENT

1. Assemble all the poles, This is what you will have:



2. Unfold the tent topside up. If using a stove, the flap should be rolled up and secured. Position the tent so that the stove and door area face opposite the prevailing wind. Stake out the corners of the tent.



3. Using one of the corner poles, measure outward from each corner of the tent on the diagonal, drive in the four steel stakes, taking care that they are squared up and line up diagonally.
4. Attach the guy ropes to the eave D-rings. The door corner rope is longer than the others.
5. Set the corner poles from the outside by sliding them under the tent. Insert the pin end into the harness then through the grommet. Stand the poles up and guy them out loosely, The door pole should be set up last. Unzip the door for easy access.
6. Set the center pole. Insert the pin end into the harness and raise the center of the tent by pushing it up with the pole.
7. Set the rest of the stakes around the perimeter and tighten up the corner guy ropes,
8. Set the intermediate side poles at the appropriate spots. Guy out In severe weather, (Note : if the zipper is hard to work on the 15 x 12, loosen the front corner guy ropes a little.)
9. Go inside the tent and check that you have inserted the poles through the harnesses.
10. Move in and enjoy your outing!