

Outhouse tent setup instructions.

1. Begin by opening up the tent and placing it on the ground so you can install the stakes.
2. Drive a stake through the stake loop on the tent into the ground. Pull the remaining corners tight and pound in the remaining stakes. All 4 corners should now be securely staked to the ground.
3. Assemble the side poles. The two shorter sections go together and the two longer sections go together as shown below.
4. Slide the 36" horizontal pole into the tent pocket above the door and slide the 39" horizontal pole through the roof pocket above the back wall of the tent.
5. Insert the pin ends of the long side poles through the holes in the 36" horizontal pole (figure 1). Insert the ring/pin assembly (at the back of the tent-figure2) into the base of the long side pole.
6. Repeat process with the short side poles raising the rear of the outhouse up.

