

Cook shack and porch setup

Adding on to your existing wall tent is a great way to add space and make your stay more comfortable.

Both cook shacks and porches are designed to overlap the existing wall tent by approximately 12". Setup the framework you are using in front of your existing wall tent.

Place the porch or cook shack onto the framework you have just setup.

There is a side opening to align as you can see in the below diagram.

Align the opening with the front corner guy ropes on your existing wall tent.

Chinch the porch or cook shack down onto the existing wall tent with the provided rope and stake the rope to the ground.

Finally stake the bottom perimeter and attach guy ropes.

